



# EXPO BOARD INSERTION GUIDELINES:

**YES!**




FOUR PINS ON EXPO BOARDLETTE ARE ALIGNED TO THE FOUR SOCKETS ON THE MAIN BOARD

**CORRECT**




**NO!**




FOUR PINS ON EXPO BOARDLETTE ARE SHIFTED ONE POSITION TO THE RIGHT ON MAIN BOARD

**INCORRECT**





**NO!**



FOUR PINS ON EXPO BOARDLETTE ARE SHIFTED ONE POSITION TO THE LEFT ON MAIN BOARD

**INCORRECT**



FOUR PIN CONNECTOR ON EXPO BOARD GOES TO FOUR POSITION SOCKET ON MAIN BOARD -  
TWO PIN CONNECTOR ON EXPO BOARD GOES TO TWO PIN SOCKET ON MAIN BOARD